BENCH IT EXPANDABLE TROUGHS

1. EXPAND TROUGHS TO DESIRED LENGTH BASED ON LENGTH OF WORKSURFACES USED.









