



CONNECT IT DROPDOWN

connect **it.**



1. FLIP WORKSURFACE OVER AND PLACE ON BLANKET TO AVOID DAMAGE.
2. ALIGN LEFT OR RIGHT LEG WITH EDGE OF WORKSURFACE AND ATTACH WITH HARDWARE PROVIDED. REFER TO LAYOUT FOR HANDEDNESS.
3. ATTACH LOWER WORKSURFACE BRACKETS AS SHOWN IN FIG. A WITH HARDWARE PROVIDED.

FIG. A



4. ATTACH TROUGH TO O-LEG AND LOWER SUPPORT BRACKET WITH HARDWARE PROVIDED. REFER TO FIG. A AND FIG. B

5. ATTACH TROUGH TO WORKSURFACE WITH HARDWARE PROVIDED. MUST USE 6" OR GREATER PHILIPS HEAD EXTENSION BIT. REFER TO FIG. A.

FIG. B








FIG. A



6. IF SCREEN IS REQUIRED, ATTACH BRACKETS TO TROUGH WITH HARDWARE PROVIDED.



7. ATTACH LEGS TO UNDERSIDE OF LATERAL FILE UNIT WITH HARDWARE PROVIDED.







8. ATTACH HALF LEG TO UNDERSIDE OF 72X18 TOP USING HARDWARE PROVIDED. SEE FIG. A.

9. ATTACH 72X18 WORKSURFACE TO TOP OF LATERAL USING DOUBLED SIDED TAPE PROVIDED.

10. IF REQUIRED ATTACH CUSHION TO TOP OF WORKSURFACE USING ATTACHED VELCRO.

11. CAREFULLY ROTATE COMPLETED MAIN DESK ASSEMBLY TO IT'S UPRIGHT POSITION AND ATTACH TO WORKSURFACE AS SHOWN WITH HARDWARE PROVIDED.





12. IF SCREEN WAS ORDERED, ALIGN HOLES ON SCREEN WITH HOLES ON SCREEN BRACKETS AND ATTACH USING SCREW (FIG. A) AND WINGNUT (FIG. B).

13. IF SCREEN WAS NOT ORDERED, USE METAL STICKERS PROVIDED TO COVER HOLES ON FRONT SIDE OF TROUGH.